

# Cabinetmaker Harmonized Level 3

## ACRONYMS AND ABBREVIATIONS

TERM	MEANING
CNC	Computer numeric control
EVA	Ethylene-vinyl acetate
G2S	Good 2 Sides
HDF	High density fibreboard
HEPA	High efficiency particulate air
in. Hg	Inches of Mercury
LDF	Low density fiberboard
LEED	Leadership in Energy and Environmental Design
MDF	Medium density fibreboard
PVA	Polyvinyl acetate
PVC	Polyvinyl chloride
rpm	revolutions per minute
UV	Ultraviolet
VOC	Volatile organic compound

**NOTE** Do **not** bring this document to your exam.  
These acronyms and abbreviations will be included in the exam reference materials.

**FORMULAS**

Stringer Length	$\sqrt{Total\ Run^2 + Total\ Rise^2}$
Unit Rise	$Total\ Rise \div Number\ of\ Risers$
Total Run	$(Number\ of\ Risers - 1) \times Unit\ Run$

**NOTE**

Do **not** bring this document to your exam.  
 These formulas will be included in the exam reference materials.